



## ADVANCED CLEAN™ 2.5 SPALET® BIDET SEAT

### Questions and Answers

---

#### Warranty

##### What is the warranty?

There is a three year warranty on all parts of the SpaLet for residential applications and a two year warranty on parts for commercial applications. Terms and conditions apply.

---

#### Install

##### Is a professional plumber required for installation?

The bidet seat is very simple to install and much like a regular toilet seat with the addition of a water hose and tee connector. You can have a professional plumber do it, but many people prefer to install it themselves.

##### What type of power is needed?

AC120V GFCI outlet. The seat consumes 1300W.

##### What type of water pressure is needed?

Minimum Inlet Water Pressure is 9 psi Flow Pressure.  
Maximum Inlet Water Pressure is 108 psi Hydrostatic Pressure.

##### How much power is consumed by the heated seat?

The heating power is 57W±10%.

##### Does this bidet seat fit my toilet?

The bidet seat fits most elongated toilets; please refer to the fit chart in the installation manual.

##### Do you need to buy anything else for installation?

Items needed for installation include standard household tools such as an adjustable wrench, Phillips and flat head screw driver.

---

#### Components

##### What comes with the product?

The following parts are included in the product:

- Seat unit (seat ring, seat lid and power cord)
- Mounting plate
- Manual
- Mounting bolts, brackets, and bushings (2 pieces each)
- Seat unit water supply hose with junction fitting
- Remote control and remote holder
- Plastic and metal clip
- Batteries (for remote control)
- Wood screw (for remote control)
- Plastic anchors (for remote control)

##### Is the remote included in the product?

The remote and batteries are included with the purchase of the Advanced Clean 2.5 SpaLet bidet seat.

---

#### Dimensions

##### What is dimension of the product?

The dimension of the product is 17-3/16" (432 mm)(W) x 21-1/8" (536 mm)(D) x 5-1/2" (140 mm)(H)

##### What is the size of the seat opening??

The inner diameter of the seat is 7-15/16" (202 mm) wide and 11-1/4" (285 mm) long.

##### How long is the power cord?

Effective length 47-1/4" or 1200 mm.

---

## Functions and Features

### **How does the self-cleaning nozzle work?**

Once the user presses the spray function, the automatic self-cleaning nozzle function rinses the nozzles prior to opening the nozzle shutter door and extending the nozzles. This function cleans the nozzle and surrounding area before and after use.

### **What is a nozzle shutter?**

The nozzle shutter is the door that covers the nozzles to keep them out of sight while providing an additional level of hygiene when not in use.

### **What are the main features?**

- Heated seat (5 temperature levels)
- Dual, adjustable, self-cleaning nozzles for independent front and back cleansing
- Adjustable water control settings: pressure (6 levels), temperature (5 levels), massage and oscillation
- Air dryer (3 temperature level)
- Soft night light for soothing guide at night
- Instant heat for on demand warm water

### **How long is the spray cycle?**

Both the back and front cleansing automatically stops after 2 minutes but can manually be stopped by pressing the Stop button at any time.

### **How much water is used during the spray cycle?**

The spray volume used is as follows:

- Back Cleansing: 0.74-1.05 pint/min (0.35-0.5L/min) (6 adjustment levels) at water supply pressure of 29 psi
- Front Cleansing: 0.74-1.05 pint/min (0.35-0.5L/min) (6 adjustment levels) at water supply pressure of 29 psi

### **How long is the drying cycle?**

Dryer function automatically stops after 4 minutes but can manually be stopped by pressing the Stop button at any time.

### **How many different water temperature settings are available?**

5 different levels of water temperature settings are available.

### **How many seat temperature settings are available?**

5 different levels of seat temperature settings are available.

### **How many dryer temperature setting is available?**

3 different levels of dryer temperature settings are available.

### **How many water pressure settings are available?**

6 different levels of water pressure settings are available.

### **What are the different spray patterns?**

5 different spray patterns: Back Cleansing, Back Oscillation, Back Massage, Front Cleansing, Front Oscillation.

### **What is Oscillation?**

Oscillation spray moves the nozzles forwards and backwards continuously allowing for a wider area to be cleansed.

### **What is the temperature of the heated seat?**

During standard use the seat has 5 adjustable temperature settings ranging from approximately 82°F - 104°F, and the seat will stay warm as long as it is on.

**What is the temperature of the water?**

The water temperature has a range of: Approximately 90°F to 104°F (6-level setting including OFF).

**What is the temperature of the air dryer?**

The temperature has a range of approximately 104°F to 131°F (3-level setting).

**Does this have an automatic seat? Slow-close seat?**

The Advanced Clean™ 2.5 SpaLet® bidet seat does have a slow-close seat and lid for user convenience but does not have an automatic open/close seat and lid.

**How does the bidet work?**

The user must sit on the seat to depress the seat sensor to allow the bidet functions to work. Then with the touch of a button, the self-cleaning nozzles extend from behind the nozzle shutter, under the seat to deliver soothing warm water for cleansing.

**How long does the heated seat stay warm?**

You can set the seat to be warm all the time by NOT using the ECO function. If you use the eco power saving mode it shuts the water and seat heater off for 8 hours then restores the power.

**Explain the eco function, how does it work?**

It reduces power consumption by turning off the water and seat heater for 8 hours. The power settings are automatically restored after 8 hours. To use this feature press the ECO button on the remote.

**How much electricity does this consume?**

Advanced Clean 2.5 SpaLet bidet seat has a rated power consumption of 1300W.

**How much electricity does the dryer consume?**

The dryer consumes 340W.

**How does the heated water supply work, where do I get the warm water from?**

The incoming water is transferred through an instant water heating element that keeps the water warm on a continuous basis during use.

**How long does the heated water last for?**

The heated water is available on demand. It will not run out.

**Where does the water come from that the bidet function uses?**

The clean water comes from the incoming water supply line. Tank water is NOT used for the bidet function.

**Does this toilet have a nightlight?**

Yes the 8012A60GRC-020 AC2.5 bidet seat have a night light function for soothing guide at night.

**Is there a child lock out feature?**

There is no specific child lock out feature but we do have a seat sensor that must be depressed to operate the bidet function. The bidet will not operate unless both the sensor is engaged and a user initiates a cleansing cycle simultaneously.

---

**How to Use****How do you adjust the nozzles for a better aim?**

Our Advanced Clean™ 2.5 SpaLet® bidet seat has 5 levels of nozzle position adjustment. These are easily changed by pressing the nozzle position arrows on the user-friendly remote.

**What type of maintenance is required/recommended?**

- Cleaning of the seat can be achieved by using a cloth and a non chlorinated cleaner.
- Changing or cleaning the nozzle tips: Press the 'Nozzle Cleaning' button for 2 seconds to extend the nozzles then pull the nozzle tips out. Push the tips back onto the nozzles once cleaned.
- Cleaning the nozzle shutter.
- Cleaning the deodorizer filter: Disconnect the power supply, shut the water valve off, remove the seat, pull the screen from under the seat out, clean the filter with a small brush or toothbrush, re-install the screen, re-install the seat, plug the seat in, turn on the water supply.

- Winterizing the seat: Only needed if the seat will not be used and the temperature of the house is lowered. Unplug the unit, turn off the water supply, depress the seat sensor or sit on the seat and activate the wash cycle to drain the tank, press the seat release button to remove from the toilet, remove the strainer on the left side of the unit, tilt the seat and completely drain the water from the seat, reattached the strainer, remove the drain plug located on the bottom of the seat, tilt the seat forward and drain, reinstall the drain plug, reinstall the seat.
- Changing the batteries.

**Is this product suitable for children?**

When small children are using this product, ensure that the proper operating procedures are followed at all times to ensure the user's safety.

**Can you customize the settings?**

Yes, you can customize your cleaning experience by adjusting the water control settings, water pressure settings (6 levels), water temperature settings (6 levels) plus the massage and oscillation features to maximize your cleansing experience.

**Can you save the customized settings?**

No, You cannot save customized user settings as in user 1, user 2 but the settings will stay the same until they are manually changed.

**How do I clean this product?**

You can clean the seat by using soft cloth and non-chlorinated cleaner.

**Do I have to mount the remote?**

No, You do not have to mount the remote if you do not have an accessible wall to mount this on but it is recommended to do so for ease of use if a wall is located within arms reach of the toilet.

**Can you turn off the deodorizer?**

Yes, you can turn the deodorizer off by pressing the "Stop" and "Bidet" buttons simultaneously for 2 seconds.

**How long does the deodorizer run for?**

Deodorizing starts when a person sits on a seat and will run for 5 seconds once the user stands up and releases the seat sensor.

**How long should I use a bidet?**

Duration of the spraying function can last up to 2 minutes and the user can stop the spray cycle at any time by pushing stop. The cycle will automatically stop at 2 minutes but can be extended up to 6 minutes using the massage function or pressing the spray cycle again. Duration for individual use will vary depending on personal cleansing needs.

**Other**

**Where is it manufactured?**

The Advanced Clean™ 2.5 SpaLet® bidet seat is manufactured in China.

**What is the weight limit for this SpaLet bidet seat?**

The seat is approved up to 264 pounds.

**Could you use it outside North America?**

This product is designed for use in the USA and Canada. Please refer to the product specifications chart in the installation manual for electrical and water requirements.